

AMPS-24

Power Supply
for the NFS-3030, NFS2-3030, and NCA-2



Power Supplies

GENERAL

NOTIFIER's AMPS-24 is an addressable power supply and battery charger with two 24 VDC outputs. It operates in either FlashScan® or CLIP (Classic Loop Interface Protocol) mode with the NFS-3030/NFS2-3030 Fire Alarm Control Panel (FACP). It can also be used as the primary power supply for the NCA-2 Network Control Annunciator.

- Addressable by NFS-3030/NFS2-3030 FACP.
- Selectable charging current charges 25 AH to 200 AH batteries.
- Isolated Signaling Line Circuit (SLC) interface.
- Brownout detection.
- Battery/battery charger supervision.
- AC loss detection and AC loss delay reporting.
- Mounts in a CAB-4 Series enclosure, EQ Cabinet Series enclosure, BB-25, BB-100, or BB-200 Battery Backbox.

SPECIFICATIONS

- **Primary (AC) power (TB3):** *for AMPS-24:* 110-120 VAC 50/60 Hz input, 4.5 A maximum; *for AMPS-24E:* 240 VAC 50/60 Hz input, 2.25 A maximum.
- **Output (TB6):** One **5 VDC @ 1.0 A**, non-power-limited (supervised). One **24 VDC @ 1.0 A**, non-power-limited (supervised, power-limited if 5V output is not used). **Maximum ripple voltage:** 250 mVrms (24 VDC and 5 VDC).
- **Source (TB2):** One +24 VDC @ 4.5 A, filtered, non-power-limited. **Maximum output:** 4.2 A when 5 V output (TB6) is used; 3.5 A when 24 VDC output (TB6) is used; 3.2 A when **both outputs** on TB6 are used. **Maximum ripple voltage:** 250 mVrms.
- **Secondary power (battery) charging circuit (TB4, TB5):** Current-limited, sealed lead-acid battery charger which will charge 25 to 200 AH batteries. **Selectable charging current:** 2.0 A or 5.0 A.
- **Wire sizes:** 12 AWG (3.1 mm²) to 18 AWG (0.78 mm²).
- **Battery fuse (F2):** 10 A, 3AB.

See page 1 for LED indicators and DIP switch settings.

PRODUCT LINE INFORMATION


AMPS-24: Addressable power supply/battery charger, two 24 VDC outputs, 120 VAC.

AMPS-24E: Same as AMPS-24, but 240 VAC.

AGENCY LISTINGS AND APPROVALS

These listings and approvals apply to the AMPS-24 power supply. In some cases, certain modules may not be listed by certain approval agencies, or listing may be in process. Consult factory for latest listing status.

- **UL:** S635
- **ULC:** CS118
- **City of Chicago**
- **City of Denver**
- **MEA:** 345-02-E
- **CSFM:** 7170-0028:223, 7165-0028:224



6883amps.jpg

- **FM:** Approved

LED INDICATORS

LED1 (green): AC, illuminates when there is AC power. Blinks slowly until AC delay expires.

LED2 (yellow): BAT/CHG, illuminates when there is a battery or charger trouble.

LED3: Not used.

LED4 (yellow): TRBL, will illuminate or blink, pause, and repeat (as specified in following descriptions) when the following troubles occur:

- **Brownout Trouble:** 1 blink (after AC delay expires).
- **Internal Power Failure:** 2 blinks.
- **Incorrect SLC Address Selection:** 3 blinks.
- **Battery Charger Shutdown:** 5 blinks.
- **Accessories Output Overload:** 6 blinks.
- **Panel Output Overload/Accessories Output Shutdown:** ON (check LED8 and/or LED10 to determine condition).

LED5 (green): SLCRXA, blinks when data is received from the SLC.

LED6 (yellow): UCFAILURE, illuminates if the microcontroller fails.

LED7 (green): SLCTXA, blinks when data is transmitted to the SLC.

LED8 (green): ACCESSORIES, illuminates when the Accessories Output (TB6) is active. OFF during overload on TB6 or when total load on TB2 and TB6 exceeds 5 A.

LED9 (yellow): GND FLT, illuminates when a ground fault is detected on any output or battery lead.

LED10 (green): 24VPANEL, illuminates when the Panel Output (TB2) is active. OFF during overload.

DIP SWITCH (SW1) SETTINGS

1.1 and 1.2:

- 1.1 OFF and 1.2 OFF: U.S. AC Delay OFF (do not use with the NFS-3030/NFS2-3030).
- 1.1 OFF and 1.2 ON: U.S. 8-hour AC Delay (do not use with the NFS-3030/NFS2-3030).
- 1.1 ON and 1.2 OFF: U.S. 16-hour AC Delay (do not use with the NFS-3030/NFS2-3030).
- 1.1 ON and 1.2 ON: Trouble Reporting for AMPS-24 addresses (SLC address, B = base): Monitor General (B);

Monitor AC Fail (B + 1); Monitor Battery (B + 2); Monitor Earth Fault (B + 3).

1.3: factory set.


1.4: factory set.

1.5: factory set.

1.6: factory set.

1.7: factory set.

1.8: ON = Disable Battery Charger (disable the battery charger when batteries are charged by another power supply); OFF = Enable Battery Charger.



FlashScan® is a registered trademark of Honeywell International Inc.
 ©2007 by Honeywell International Inc. All rights reserved. Unauthorized use of this document is strictly prohibited.



This document is not intended to be used for installation purposes.
 We try to keep our product information up-to-date and accurate.
 We cannot cover all specific applications or anticipate all requirements.
 All specifications are subject to change without notice.



Made in the U.S. A.

For more information, contact Notifier. Phone: (203) 484-7161, FAX: (203) 484-7118.
www.notifier.com